

Model	Steps	Localized number display	Go to	Correct	Answer Memory	Double Check	Insert / Delete	Digits	Independent memory	GT	%	Profit margin %	MU	<input type="checkbox"/>	+/-	<input type="checkbox"/>	3-digit comma markers	Tax calculation	5/4	Cut	Up	Decimal selector	ADD mode	Power supply	Dimensions H×W×D (mm)	Approximate weight (g)		
DJ-240D/DJ-220D	150 STEPS CHECK	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	14/12	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	0,1,2,3,4	<input type="radio"/>	Two-way power	38×146×219	285
DJ-120D	150 STEPS CHECK	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	—	—	—	12	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	0,1,2,3,4	<input type="radio"/>	Two-way power	35×140×191	205
JJ-120D	150 STEPS CHECK	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	—	—	—	12	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	—	<input type="radio"/>	<input type="radio"/>	—	<input type="radio"/>	<input type="radio"/>	0,1,2,3,4	<input type="radio"/>	Two-way power	25.2×107×178.5	140
MJ-120D/MJ-100D	150 STEPS CHECK	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	—	—	—	12/10	<input type="radio"/>	—	<input type="radio"/>	—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	—	—	—	—	—	—	—	Two-way power	30.1×123×140	130

Model	Digits	Independent memory	Cost/Sell/Margin	GT	%	Profit margin %	MU	<input type="checkbox"/>	+/-	<input type="checkbox"/>	3-digit comma markers	Time calculation	Tax calculation	Exchange calculation	5/4	Cut	Up	Decimal selector	ADD mode	Power supply	Dimensions H×W×D (mm)	Approximate weight (g)	Others
DJ-240D/220D	14/12	<input type="radio"/>	—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	—	<input type="radio"/>	—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	0,1,2,3,4	<input type="radio"/>	Two-way power	38×146×219	285	150 STEPS CHECK & Localized Number Display
DJ-120D	12	<input type="radio"/>	—	<input type="radio"/>	<input type="radio"/>	—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	—	—	—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	0,1,2,3,4	<input type="radio"/>	Two-way power	35×140×191	205	150 STEPS CHECK & Localized Number Display
JJ-120D	12	<input type="radio"/>	—	<input type="radio"/>	<input type="radio"/>	—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	—	—	—	<input type="radio"/>	<input type="radio"/>	—	0,1,2,3,4	<input type="radio"/>	Two-way power	25.2×107×178.5	140	150 STEPS CHECK & Localized Number Display
MJ-120D/100D	12/10	<input type="radio"/>	—	—	<input type="radio"/>	—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	—	—	—	—	—	—	—	—	Two-way power	30.1×123×140	130	150 STEPS CHECK & Localized Number Display